



Astor Rectangle Dining Table




Furnt
www.furnt.co.uk


PART LIST



#1



#2



#2

HARDWARE LIST

A		BOLT (Ø1/4"x2-3/4")	08
B		FLAT WASHER	08
C		SPRING WASHER	08

NOTE: Find the label of "Hardware Enclosed" on one of the carton corner then follow the red ribbon to get the hardware bag.



TOOLS REQUIRED

ALLEN KEY		SUPPLIED
-----------	---	----------

IMPORTANT:

- 1. Do not tighten bolts completely until all bolts are completely lined up and inserted into holes / nuts.
- 2. Do not over tighten screws and bolts to avoid stripping.
- 3. Please use hand tools to assemble this product. Do not use power tools.
- 4. For ease of assembly, two adults are recommended

1.



A		08
B		08
C		08

2.

